





Painted wood requires regular maintenance to preserve the both effectiveness of the 10-year guaranteed protection and the appearance.

PAINTED WOOD CARE

FOREWORD / The colours are vulnerable to the exposure. This means that darker colours absorb more heat and UVs. Possible size and colour variations may appear. For this type of cladding, prefer facades

WHAT TO DO AFTER 10 YEARS / Between the 10 and 20 years following installation, the colour and shine of your cladding may fade depending on the exposure. To guarantee that the initial appearance of your cladding remains, you may need to repaint all or part of your facade.

MAINTAIN		HOW TO PROCEED?
How do you keep the aesthetics of a painted timber product?		/Spray the neutral wood detergent. /Leave it to act for a few minutes. /Clean the surface using a soft cloth /Leave to dry /After cleaning, a wood revitaliser can be applied to restore the shine
NATURAL ALTERATIONS	ORIGIN	COMMENT PROCÉDER ?
DUST LAYERS	Natural and can accumulate on any materials used outdoors	 / Spray the neutral wood detergent. / Leave it to act for a few minutes. / Clean the surface using a soft cloth / Leave to dry / After cleaning, a wood revitaliser can be applied to restore the shine
MOSS STAINS	These are mainly caused by the exposure. They can appear as greenish stains	
SUPERFICIAL SCRATCHES	Can be caused by everyday accidents (handles, pedals, garden tools, animal claws, etc.)handles, pedals, garden tools, animal claws, etc.)	 / Rub the scratched zone using a non-fluff cloth and a neutral detergent for wood / Leave to dry for at least 1h depending on the temperature / In dry weather, apply a first coat of finishing paint using a brush or paint brush on the scratched zones / Leave to dry for 4h / Apply a second coat of paintin the same way

CONSUMPTION

Paint repairs: 1L pot available in all colours Applicable surface area: 4 m² per coat per L